

SIGNIFY

55"

4K

ULTRA HD
LED LCD TV



Quick Start Guide

EA0815

Getting Started

Please refer to the instruction manual for full instructions on how to operate the Signify® 55" 4K Ultra HD LED LCD TV.


1 PARTS LIST

In the box you will find:

- 1 x 55" 4K Ultra HD LED LCD TV
- 1 x Remote control (not pictured)
- 2 x AAA batteries (not pictured)
- 2 x Base stands (including 4 x screws)


WHAT YOU WILL NEED

- 1 x Phillips head screwdriver (for stand installation)
- 1 x Antenna cable




2 CONNECTIONS

1. HEADPHONES OUTPUT
2. HDMI1 (supports 4K)
3. HDMI2 (supports 4K)
4. PC AUDIO INPUT
5. VGA INPUT
6. AV INPUT
7. COAXIAL OUTPUT
8. USB INPUT
9. USB INPUT
10. Y/Pb/Pr INPUT (COMPONENT)
11. ANTENNA INPUT
12. HDMI3 (supports full HD 1080p resolution)



3 INSTALLATION AND POWER CONNECTION

1. Install the stand (see page 13 of the instruction manual).
2. Connect one end of the antenna cable to the antenna socket of the TV and the other end to the antenna wall socket.
3. Insert the batteries into the remote control.
4. Connect the TV power cord into the mains power socket and switch it on.
5. Press the power button located on the lower right hand side of the TV front panel. The indicator light will illuminate green and the TV screen will display the First Time Installation menu.



4 FIRST TIME INSTALLATION MENU

The on-screen display will contain easy instructions for setting up the unit (see page 22 of the instruction manual). Select the desired Language, Country and Energy Model by using the ▲/▼/◀/▶ buttons on the remote control. Then press the **OK** button on the remote control to initiate Auto Tuning. The TV will automatically tune all the digital channels.



5 You are now ready to start watching your Signify® 4K Ultra HD LED LCD TV set.

NOTE: At this stage, TV programming in Australia is not available in 4K Ultra HD. For instructions on how to watch 4K Ultra HD see page 52 of the instruction manual.

Item Code: EA0815